


**RANDOM ORBITAL SANDER**



NO.	PART NO.	DESCRIPTION	QTY	NO.	PART NO.	DESCRIPTION	QTY
01	OB-01	Regulator	1	28	OB-28.1	Washer	2
02	OB-02	O-ring	2	29	E-29	Washer	1
03	OB-03	Snap Ring	1	30	ST70407	Rotor Key	1
04	OB-04	O-ring	1	31	STS5603-31	2.5 MM Motor Shaft Balancers (5")	1
05	A-05	Valve Stem	1	31	STS5603-29	2.5 MM Motor Shaft Balancers (6")	1
06	OB-06	Washer	1	31	STS560-31	5 MM Motor Shaft Balancers (5")	1
07	STOB-08	Valve	1	31	STS560-29	5 MM Motor Shaft Balancers (6")	1
08	OB-09-1	Spring	1	32	OB-30	Snap Ring	1
09	70426	Air Inlet	1	33	OB-31.1	Bearing (6001LU)	1
10	2HG-02	Cone Muffler	1	33	OB-31.2	Bearing (6001)	1
11	A-11	Exhaust Sleeve	1	34	OB-33	Snap Ring	1
12	OB-13	Lever	1	35	S560-34	Shaft	1
13	OB-14	Pin	1	36	OB-101-34.1	Housing Cover (2.5MM)	1
14	A-14	Protecting Rubber	1	36	OB-101-34	Housing Cover (5 MM)	1
15	A-15	Housing	1	37	A-37	Shroud (N5,N6)	1
16	A-16-3	Skirt	1	37A	OB-101-41	Shroud (C5,C6) (S5,S6)	1
17A	OB-16	Rubber Bushing	1	38	BTOB-38-5V0	Pad (N5)	1
17	OB-16.2	Rubber Bushing	1	38	BTOB-38-5V6	Pad (C5,S5)	1
18	70410	Snap Ring	1	38	BTOB-38-6V0	Pad (N6)	1
19	OB-18	Bearing (6000ZZ)	1	38	BTOB-38-6V6	Pad (C6,S6)	1
20	STOB-19	Rear Plate	1	39	BTOB-39-22	Stop Spanner	1
21	OB-20	Rotor Blade	5	40	S560-40.1	Vacuum Adapter (S5, S6)	1
22	STOB-21	Rotor	1	41	OB-42.1	Muffler Body	1
23	A-23	Pin	1	42	S560-41.1	Vacuum Adapter (CS,C6)	1
24	STOB-22	Cylinder	1	43	STOB-46-2	Rubber Hose & Bag (S5,S6)	1
25	OB-24	O-ring	1	44	OB-16.1	Washer	1
26	STOB-25	Front Plate	1	45	81326	Pin	1
27	OB-26	Bearing 6002ZZ)	1				